

## How to use Washing machine

1. Put clothes into washing machine.
2. Put laundry detergent into washing machine.
- ✖ **Don't use detergent too much.**  
**Japanese detergent is good quality. Just little OK!!**
3. Close the lid.
4. Push the switch on button.
5. Push the auto button.
6. About 60 minutes later finish.

